

# DC One X Headset Conversion Guide

Tools Needed: Small Phillips Head screwdriver, Small Flathead Screwdriver

1. Dissassemble DC One X starting by removing headset cushion. Then free wires from headband. The Small flathead screwdriver is helpful to gently pry wire ties free as shown in the picture. Next remove the 4 screws holding earmuffs to the headband. Keep these screws as you will need them later



2. With headband removed, Time to route everything through the helmet to hide the wire. Under the padding on the side and top of the helmet.
3. Now with the wiring routed you can install the earmuffs to the helmet. To do this slide the small adaptor washers into the peltor guideposts connected to the helmet. The guideposts can be removed from the metal guides if necessary. Once adaptor washers are lined, up insert screw and secure guideposts to earmuffs.

